



# LED 安装说明书

## LED Light bar kit installation manua

### 配件清单 | Parts List

1. 灯管 LED Light bar
2. 右支架 Right bracket
3. 左支架 Left bracket
4. 安装螺丝 Screw
5. 电源线 Power cord
6. 右灯架 (含开关) Right light bracket(with switch)
7. 左灯架 Left light bracket



### 安装步骤 | Installation steps

- 1 如图所示安装灯条组件  
Install the light bar assembly as shown
- 2 将组装好的灯条组件固定在打印机上，（从打印机顶部的两边各拆卸2个螺丝来固定），将电源线从打印机上的走线口穿过（需提前敲掉走线口的预留封盖）  
Fix the assembled light bar assembly on the printer (Remove two screws from each side of the top of the printer to secure it), Pass the power cord through the cable outlet on the printer (It is necessary to knock off the reserved cover of the wiring outlet in advance)
- 3 将上一步接入的电源线并联在主板上的电源端口处即可（红色为正，黑色为负）  
Just connect the power cord to the power port on the motherboard in parallel (red wire to positive pole, black wire to negative pole)
- 4 组装好后按下开关既可点亮灯条  
After assembly, press the switch to light up the light bar

